



National
Operational
Guidance

Control measure

Joint working with helicopter services



NFCC
National Fire
Chiefs Council

Developed and maintained by the NFCC



National
Operational
Guidance



NFCC
National Fire
Chiefs Council

Contents

Control measure - Joint working with helicopter services 3



Control measure - Joint working with helicopter services

Control measure knowledge

When carrying out joint working with helicopter services, personnel may be required to approach, board, load or leave a helicopter. At all times personnel should closely follow the instructions of the aircrew.

Personnel should approach from the front of the helicopter, in full view of the pilot. The exception to this is for military Chinook helicopters, which should be approached from the rear in full view of the aircrew loadmaster.

Personnel should avoid areas near to the tail rotor and the exhaust outlets. Equipment should be carried at a low level, and not in an elevated position to avoid the main rotors.

If the helicopter has landed on sloping ground, personnel should approach or leave the helicopter on the downslope side, to maximise rotor clearance.

Further information is shown in the National Police Air Service (NPAS) Helicopter Operations Awareness diagrams below. However, fire and rescue services should consider seeking training from the helicopter service providers who are commonly used in their area.



Helicopter operations awareness Source: National Police Air Service

Strategic actions

Fire and rescue services should:

- Develop mutual aid arrangements and emergency planning for joint working with local helicopter service providers

Tactical actions

Incident commanders should:

- Follow the instructions of the aircrew and pilot when approaching and leaving helicopters